BARIATRIC REVOLUTION CHAIR

FITTING INSTRUCTIONS

1.



Remove seat and chair frame from box.

2.



Attach handle to chair base: handle lever is located to the left or right side.

3.



Invert seat with chair back toward you. It is best supported on a small sturdy box.

4.



Invert chair frame over the seat.
Rotate base to align 2 of the bolt holes.

5.



Screw bolts with washers in (not too tight), with a 3 point Phillips head screwdriver.
Rotate the base in the opposite direction to access the other 2 bolt holes and screw bolts with washers. Now fully tighten all screws.

6.



Set chair upright. Make sure the handle is at the front left or front right side of seat.